




No		No. Part	Description	Qty
1		LS1-ASSY-02-R0	Assy Main Cabinet	1 Pc
2		EA0584A	Button Ø88 Blue	20 Pcs
3		LS1-FM-23-R0	Stopper heder	1 Pc
4		LS1-FM-04-R1	Back Cover Side	1L/1R
5	5A	LS1-FW-07-R1	Base PCB	1 Pc
	5B	BAFB66A	PCB	1 Pc
	5C	BAFB152	PCB	1 Pc
	5D	BAFB106	PCB	1 Pc
	5E	BAFB162	PCB	1 Pc
6		LS1-FM-03-R1	Side Main Cabinet	1L/1R
7	7A	LS1-FM-22-R0	Reflektor Side Cabinet	1L/1R
	7B	EA0597	LED Strip	
8		LS1-FP-13-R0	Acrylic Side Cabinet	1L/1R
9	9A	EA1003	Power Supply	1 Pc
	9B	LS1-FM-10-R0	Bracket Power Supply	1 Pc
10	10A	HM0242	Mounting Nilon	7 Pcs
	10B	LS1-FM-07-R0	Base Mounting (Part A&B)	5A/2B
11		LS1-FM-25-R0	Ticket Holder	1 Pc
12		LS1-FP-16-R0	Spacer Base Cashbox	1 Pc
13		LS1-FW-15-R0	Spacer Cashbox	1 Pc
14	14A	LS1-SA-12-R0	Housing Cash Box SA	1 Pc
	14B	LS1-SA-06-R0	Cash Box SA	1 Pc
15	15A	LS1-FM-15-R0	DB Box Front	1 Pc
	15B	EA0649	Emy Filter	1 Pc
	15C	EA1356	Bending Post	1 Pc
	15D	LS1-FM-16-R0	DB Box Housing	1 Pc
16		LS1-FM-26-R0	Stopper Back Cover Down (Part-A&B)	1A/2B
17		LS1-FM-09-R0	Bracket PCB	1L/1R
18	18A	LS1-FM-17-R0	Cover Speaker	2 Pcs
	18B	LS1-FM-31-R0	Parvored speaker	2 Pcs
	18C	EA1201	Speaker	2 Pcs
19	19A	LS1-FW-05-R0	Back Cover (Part-A&B)	1 Pc
	19B	LS1-FM-28-R0	Stopper Door (Part-B&C)	1B/1C
	19C	HM0004	Lock Angel	1 Pc
	19D	LS1-FM-27-R0	Parvored Vent	2 pcs
20	20A	LS1-FM-11-R0	Bracket Service	2 pcs
	20B	EA0519 & EA0520	Button 2 colours (Red&Green)	2 pcs
	20C	EA1252A	Coin Counter	2 pcs
	20D	EP0602 & EF0688	Volume Potensio	2 pcs
21		LS1-FM-28-R0	Stopper Door (Part-A)	1 pc