






STACKER MINI



	NO	PART NO	DESCRIPTION	QTY
	01	SM A003	FRONT DOOR ASSEMBLY	1
SUB ASSY	01A	SM-FM-16-R0	FRONT GLASS LOWER&UPPER CLAMP	2
	01B	SM-FM-19-R0	FRONT GLASS RIGHT&LEFT CLAMP	2
	01C	SM-FG-01-R0	FRONT GLASS DOOR	1
	01D	SM-SA-36-R0	FRONT DOOR ASSY METAL ONLY	1
	-	AT3702	STICKER PLAY INSTRUCTION	1
	02	SM E005	POWER ASSEMBLY	1 SET
SUB ASSY	02A	EA1003	POWER SUPPLY +5V 15A +12V 4A -5V 1A	1
	02B	EA0311	STARTER BASE UL	2
	02C	SA-FM-06-R0	BRACKET BALLAST	1
	02D	EA0325	BALLAST 240V, 15W	1
		EA1359	BALLAST 110V, 15W	1
	-	SM E006	POWER HARNESS	1
	03	SM A008	COINDOOR ASSY	1
SUB ASSY	03A	HM0004	EAGLE LOCK	1
	03B	SM-FM-41-R0	T HANDLE COVER	1
	03C	SM-SA-33-R0	COIN DOOR 1 DBA 1 COIN MECHANIC METAL ONLY	1
		SM-SA-41-R0	COIN DOOR 2 COIN MECHANIC METAL ONLY	1
	03D	-	DOLLAR BILL ACCEPTOR	1
	03E	HM0014	COIN MECHANISM	1
	03F	EA0520	SWITCH SMALL ROUND GREEN BUTTON	1
	03G	EA0519	SWITCH SMALL ROUND RED BUTTON	1
	-		HARNESS COIN DOOR 1 DBA 1 COIN MECHANIC	1
	-	SM H002	HARNESS COIN DOOR 2 COIN MECHANIC	1